

A. General

There is a diagnosis program integrated into the control unit (N2/2), which checks the control unit and the airbag system components.

When a fault is detected:




- warning lamp (A1e15) does not light up in steering lock key position "1"
- does not go out after 4 s
- lights up when the vehicle is driven

The warning lamp goes out again when no more faults are present; however, the fault remains stored. The stored fault can be called up in the form of a flashing pulse via warning lamp (A1e15) or digitally via a pulse meter. The number of flashing pulses indicates the fault detected (refer to table of pulse displays).

Test conditions

- During pulse output, the test coupling/plug connection for airbag (X29/9) remains contacted.
- Battery voltage (11 – 14 V).

Special tools



Conventional tool

Multimeter

e.g. Sun, DMM-5 or
Hermann, Avometer 2003
Fluke, 23

B. Trouble diagnosis using the pulse meter

Notes on the pulse display

If no fault is indicated via the pulse display in the event of a complaint, the function test, section "C/d" must be performed.

The number 1 signifies that no fault is recorded in the electronic system. All other numbers are assigned to a certain fault circuit.

The numbers 1 through 10 appear on the display of the pulse meter.

- If the light-emitting diode "U Batt:" lights up after connection, both the pulse meter and the power supply for the pulse meter are in order.

Testing

- Connect pulse meter in accordance with connection diagram.

Note

Light-emitting diode "U Batt:" in the display must light up.

If it fails to do so switch multimeter to "volts" position and

- a) Test socket 1 of test coupling X92 to battery positive (11 – 14 V).
- b) Test socket 6 of test coupling X92 to socket 1 (6 – 12 V).

- Press start button for between 2 and 4 seconds.
- Read off displayed pulse output and note down.
- Press start button again for between 2 and 4 seconds. The previous number appears again if there are no more faults in the system.
- Eliminate noted fault (pulse output) in accordance with the fault-finding diagram.
- Test individual components.

Clearing the fault memory

The displayed pulse must be cleared as follows after a fault has been rectified:


- Press start button and call up the eliminated fault, then press start button for at least 6 – 8 seconds.

Note

Each pulse displayed must be cleared individually.

- No display: Stored fault has been cleared.
- Number displayed (> 1): further faults in system.

a) Connection diagram for pulse meter



- 013 Pulse meter
- G1 Battery
- X92 Test coupling for diagnosis, 8-pin, flashing code

1913 - 15443

The number of pulses indicates whether there is a fault and which fault is present, or which component is faulty.

Pulse display 10 signifies that the control unit has activated the output stages of the airbag. This pulse display cannot be cleared. **The control unit must be renewed.**

Pulse display	Fault
1	No fault stored
2	Control unit
3	Triggering circuit, driver's airbag
4	Triggering circuit, passenger's airbag
5	Driver's belt buckle
6	Passenger's belt buckle
7	Resistance, passenger's seat, airbag
8	Low voltage
9	Warning lamp
10	Control unit


b) Connection diagram for socket box

Note

The negative terminal of the battery must be disconnected and covered before disconnecting the test coupling/plug connection for airbag, 10-pin.

Connection diagram for socket box

- 01 Test coupling/plug connection, airbag, 10-pin
- 02 Test cable
- 03 Multimeter
- 04 Socket box



C. Test program with socket box and multimeter

Symbols for testers:








Socket box



Battery







Multimeter

Display	Test step/ scope of test	Tester/ test connection	Operation/ requirement	Reference value	Possible cause/remedy
1	1	-	-	-	No fault stored
2	Control unit		Ignition: ON Clear pulse display 2. Pulse display 2 cannot be cleared Ignition: OFF Disconnect battery -ve terminal, cover; disconnect test coupling (X29/9).	Pulse display 2 cleared	- Renew control unit
3 ¹⁾	Driver's airbag Collector ring Cables as far as (X29/9)	3   5	Ignition: OFF Disconnect battery -ve terminal and cover.	2 – 5 Ω	Airbag unit, 4 carbon contacts, collector ring, cables (open circuit, short circuit)
		   5	Disconnect test coupling (X29/9) and connect test cable, turn steering wheel to full lock left and right.	∞ Ω	Short to ground


¹⁾ If test with pulse display 3 is in order but pulse display cannot be cleared, continue by testing cables in accordance with section "C/a".

Display	Test step/ scope of test	Tester/ test connection	Operation/ requirement	Reference value	Possible cause/remedy
4 ¹⁾	Passenger's airbag		Ignition: OFF Disconnect battery -ve terminal and cover.	2 - 5 Ω	Passenger's airbag Cables
			Disconnect test coupling (X29/9) and connect test cable	∞ Ω	Cables
				2 - 5 Ω	Passenger's airbag Cables
5	Driver's belt buckle		Disconnect plug connection (S68/3x). Belt buckle not inserted.	400 ± 10 Ω	Belt buckle
	Cables		Inserted	100 ± 10 Ω	
	Cables		Disconnect plug connection (S68/3x).	< 1 Ω	Open circuit in cable
	Cables		Ignition: OFF Disconnect battery -ve terminal and cover. Disconnect test coupling (X29/9). Disconnect plug connection from control unit.	< 1 Ω	Open circuit in cable
	Cables			∞ Ω	Short to ground










¹⁾ If test for pulse display 4 is in order but pulse display cannot be cleared, continue by testing cables in accordance with section "C/b".

Display	Test step/ scope of test	Tester/ test connection	Operation/ requirement	Reference value	Possible cause/remedy
6	Passenger's belt buckle		Disconnect plug connection (S68/4x). Belt buckle not inserted.		Belt buckle
			Belt buckle inserted.	$400 \pm 10 \Omega$ $100 \pm 10 \Omega$	
	Cables		Disconnect plug connection (S68/4x).	$< 1 \Omega$	Open circuit in cable
	Cables		Ignition: OFF Disconnect battery -ve terminal and cover. Disconnect test coupling (X29/9). Disconnect plug connection from control unit.	$< 1 \Omega$	Open circuit in cable
	Cables			$\infty \Omega$	Short to ground

Display	Test step/ scope of test	Tester/ test connection	Operation/ requirement	Reference value	Possible cause/remedy
7	Resistance, passenger's seat, airbag		Ignition: OFF Disconnect battery -ve terminal and cover. Disconnect test coupling (X29/9). Disconnect plug connection from control unit.	100 $\Omega \pm 10$	Open circuit
8	Supply voltage		Ignition: OFF Disconnect battery -ve terminal and cover. Disconnect test coupling (X29/9). Ignition: ON	11 - 14 V	Check battery, alternator, ignition starter switch X28/2, and cable from X28/2 to N2/2 as per wiring diagram. Note To test the cable: Ignition: OFF Disconnect battery -ve terminal and cover. Disconnect test coupling (X29/9). Disconnect plug connection from control unit.

Display	Test step/ scope of test	Tester/ test connection	Operation/ requirement	Reference value	Possible cause/remedy
9	Warning lamp Supply voltage	<p style="text-align: center;">A1e15</p>  <p style="text-align: center;">pink pink/yellow black/red</p>	Ignition: ON Ignition: ON	Warning lamp lights up 11 – 14 V	Warning lamp Warning lamp Check cables from A1e15 to N2/2 and X28/2 or to fuse box as per wiring diagram, for open circuit, short circuit and short to positive. Note To test the cable: Ignition: OFF Disconnect battery -ve terminal and cover. Disconnect test coupling (X29/9). Disconnect plug connection from control unit.
10	Control unit	–	Ignition: OFF Disconnect battery -ve terminal and cover. Disconnect test coupling (X29/9).	–	Renew control unit.

a) Testing cables if pulse display 3 appears

Display	Test step/ scope of test	Tester/ test connection	Operation/ requirement	Reference value	Possible cause/remedy
3	Check cables between X29/9 and N2/2 for open circuit	X29/9  N2/2 5 — 2	Ignition: OFF Disconnect battery -ve terminal and cover.	< 1 Ω	Open circuit
		X29/9  N2/2 3 — 6	Disconnect test coupling (X29/9). Disconnect plug connection from control unit.	< 1 Ω	
	Check cables between X29/9 and N2/2 for short circuit	X29/9  X29/9 5 — 3		∞ Ω	Short circuit
	Check cables between X29/9 and N2/2 for short to ground	⊥  X29/9 ⊥ — 5		∞ Ω	Short to ground
		⊥  X29/9 ⊥ — 3		∞ Ω	Short to ground
	Check cables of X29/9 for short to positive	X29/9   5 — +		∞ Ω	Short to positive
		X29/9   3 — +		∞ Ω	Short to positive

b) Testing cables if pulse display 4 appears


Display	Test step/ scope of test	Tester/ test connection	Operation/ requirement	Reference value	Possible cause/remedy
4	Cables between X29/9 and X29/9	<p>X29/9 5 — — 6</p>	Ignition: OFF Disconnect battery -ve terminal and cover. Disconnect test coupling (X29/9). Disconnect plug connection from control unit.	< 1 Ω	Open circuit
	Check cables between X29/9 and N2/2 for open circuit	<p>X29/9 N2/2 5 — — 2 8 — — 13 7 — — 14</p>		< 1 Ω	Open circuit
	Check cables between X29/9 and N2/2 for short circuit	<p>X29/9 5 — — 7 5 — — 8 7 — — 8</p>		∞ Ω	Short circuit
	Check cables between ⊥ and X29/9 for short to ground	<p>⊥ X29/9 ⊥ — — 5 ⊥ — — 7 ⊥ — — 8</p>		∞ Ω	Short to ground
	Check cables from X29/9 for short to positive	<p>X29/9 ⊕ 5 — — + 7 — — + 8 — — +</p>		∞ Ω	Short to positive

d) Testing if no pulse display appears

Test condition

- Test coupling/plug connection for airbag (X29/9) contacted.
- Battery voltage 11 – 14 V
- Pulse meter connected in accordance with connection diagram (— 1 black cable, — 6 yellow cable).
- Ignition switched on
- Start button on pulse meter pressed for 2 – 4 s.

Special tools



Conventional tester

Multimeter

e.g. Sun, DMM-5 or
Avometer 2003

Testing

- 1 Check that socket 6 is correctly clamped in the 8-pin test coupling for diagnosis (X92).
- 2 Check cables in accordance with test program using multimeter and electrical connection set.

Test program

Symbol for tester:




Multimeter

Display	Test step/ scope of test	Tester/ test connection	Operation/ requirement	Reference value	Possible cause/remedy
	Cable between ┌ and X92 for open circuit		Ignition: OFF	$< 1 \Omega$	Open circuit in cable
	Cable between X92 and N2/2 for open circuit		Ignition: OFF Disconnect battery -ve terminal and cover. Disconnect test coupling X29/9. Disconnect plug connection from control unit (N2/2)	$< 1 \Omega$	Open circuit in cable
	Check cable between ┌ and X92 for short to ground			$\infty \Omega$	Short to ground

Remedy:

If all values in the table are in order, the control unit must be renewed.


D. Wiring diagrams



Electrical wiring diagram for driver's airbag with belt tensioners (as of 09/87)

A1e15	RS warning lamp (airbag)	W10	Ground, battery
N2/2	Control unit, belt tensioner with airbag	W12	Ground, center console
R12/1	Detonator, belt tensioner, front left	X28/2	Plug connection, power supply for airbag with belt tensioner
R12/2	Detonator, belt tensioner, front right	X28/4	Plug connection, airbag/detonator
R12/3	Detonator, airbag	X28/5	Collector ring, detonator, airbag, 2-pin
S68/3	Belt buckle switch, airbag/belt tensioner, driver	X29/9	Test coupling/plug connection, airbag, 10-pin
S68/3x	Plug connection, belt buckle switch, airbag/belt tensioner, driver	X92/1	Test coupling for diagnosis, 8-pin (flashing code), ground (socket 1, 4-pin)
S68/4	Belt buckle switch, airbag/belt tensioner, passenger	X92/6	Flashing code, airbag (socket 6, 1-pin)
S68/4x	Plug connection, belt buckle switch, airbag/belt tensioner, passenger	a	Fuse box, terminal 15 R, unfused side

All pins in the plug are short-circuited when the 10-pin test coupling/plug connection for airbag is disconnected. When the connection for the belt tensioner detonators (R12/1, R12/2) and the airbag detonator (R12/3) is disconnected, the detonators are short-circuited.




Electrical wiring diagram for driver's and passenger's airbag with belt tensioners (as of 09/88)

A1e15	SRS warning lamp (airbag)	W10	Ground, battery
N2/2	Control unit, belt tensioner with airbag	W12	Ground center console
R12/1	Detonator, belt tensioner, front left	X28/2	Plug connection, power supply, airbag with belt tensioner
R12/2	Detonator, belt tensioner, front right	X28/4	Plug connection, airbag/detonator
R12/3	Detonator, driver's airbag	X28/5	Collector ring, detonator, airbag, 2-pin
R12/4	Detonator 1, passenger's airbag	X29/9	Test coupling/plug connection, airbag, 10-pin
R12/5	Detonator 2, passenger's airbag	X92	Test coupling for diagnosis, 8-pin (flashing code)
S68/3	Belt buckle switch, airbag/belt tensioner, driver	a	Fuse box, terminal 15 R, unfused side
S68/3x	Plug connection, belt buckle switch, airbag/belt tensioner, driver		
S68/4	Belt buckle switch, airbag/belt tensioner, passenger		
S68/4x	Plug connection, belt buckle switch, airbag/belt tensioner, passenger		

Note

Eight plug pins are short-circuited when the test coupling/plug connection (X29/9) for airbag, 10-pin, is disconnected. When the connection for the belt tensioner detonators (R12/1, R12/2) and the airbag detonators (R12/3, R12/4, R12/5) is disconnected, the detonators are short-circuited.

E. Arrangement of components




P91-0003-61 A

A1e15 RS/SRS warning lamp, airbag
 N2/2 Control unit, belt tensioner with airbag
 R12/1 Detonator, belt tensioner, front left
 R12/2 Detonator, belt tensioner, front right
 R12/3 Detonator, airbag
 R12/4 Detonator 1, airbag (passenger)
 R12/5 Detonator 2, airbag (passenger)

S68/3 Switch, belt buckle/airbag, belt tensioner, driver
 S68/4 Switch, belt buckle/airbag, belt tensioner, passenger
 X29/9 Test coupling/plug connection, airbag, 10-pin
 X92 Test coupling for diagnosis, 8-pin (flashing code)

F. Arrangement of plug connections



S68/3x Plug connection, belt buckle switch, airbag/belt tensioner, driver
 S68/4x Plug connection, belt buckle switch, airbag/belt tensioner, passenger
 X28/2 Plug connection, power supply, airbag with belt tensioner

X28/4 Plug connection, airbag/detonator
 X28/5 Collector ring, detonator, airbag, 2-pin
 X29/9 Test coupling/plug connection, airbag, 10-pin
 X92 Test coupling for diagnosis, 8-pin (flashing code)