
A. Up to 11/92




Depressurize the cooling system with the radiator

cap	Open
Hose clamps (I)	Loosen
Both hoses	Pull off
Coupling (2)	Pull off
Mono valve (Y19) from rubber buffer (3)	Push out
In reverse order	Install

Installation instruction

Before pressing on the coupling (2), check the two sleeves for contact, correct by bending if required. After filling in the coolant, check cooling system for leaks.

B. As of 12/92



Installation note

Before pressing on the coupling (2), check the two sleeves for contacting and bend, if necessary. After pouring in the coolant, check the cooling system for leaks.