

A1	Instrument cluster	14M
A1r1	Instrument illumination rheostat	15M
A2	Radio	14A
A2F1	Fuse (inside radio)	19A
A28	Antenna (radio, CB, telephone)	19M
A35	CTEL transmitter-receiver	15M
B6	Hall-effect speed sensor	16M
F1	Fuse and relay box	
F1-3	Fuse 3, circuit 58R	12L
F1-9	Fuse 9, circuit 30	4L 12L
F1-C	Fuse C, circuit 30	17L
H4/5	Left front door speaker	1M
H4/5x1	Left front door speaker connector	1K
H4/6	Right front door speaker	6M
H4/6x1	Right front door speaker connector	6K
H4/7	Left rear speaker group	3M
H4/7h1	Speaker 1	3M
H4/7h2	Speaker 2	4M
H4/7h1x1	Left rear speaker group speaker 1 connector	3K
H4/7h2x1	Left rear speaker group speaker 2 connector	3K
H4/8	Right rear speaker group	8M
H4/8h1	Speaker 1	8M
H4/8h2	Speaker 2	9M
H4/8h1x1	Right rear speaker group speaker 1 connector	8K
H4/8h2x1	Right rear speaker group speaker 2 connector	8K
H4/9	Left front speaker	2M
H4/9x1	Left front speaker connector	2K

H4/10	Right front speaker	7M
H4/10x1	Right front speaker connector	7K
M11	Automatic antenna (radio/telephone) (USA)	18M
N2/4	Seat belt warning module (USA)	14M
N40/1	Left speakers audio power amplifier	3A
N40/2	Right speakers audio power amplifier	7A
R3	Front cigar lighter (with ashtray illumination)	13M
R3e1	Illumination	13M
R3r1	Heating element	13M
R3x1	Illuminated cigar lighter connector	12K
W6	Ground (left wheelhousing in trunk)	
W12	Ground (center control)	
W18	Ground (left front seat crossmember)	
W31	Ground strap (antenna)	
	Ground location without designation, component grounded directly on engine, chassis or body.	
X1/4	Automatic antenna connector	17H
X1/5	Sound system feed connector (amplifier - circuit 30)	4H
X1/8	Taillamp harness, radio/sound system connector	11H
X2/2	VSS connector (radio) (2-pole)	15E
X53/5	Hall-effect sensor multipoint connector (VSS)	16H
Z	Connector sleeve (solder joint in harness)	5D
Z7	Circuit 30 connector sleeve	4D
Z28/5	Left front door speaker group connector sleeve (+ signal)	2G
Z28/6	Left front door speaker group connector sleeve (? signal)	1G

Z28/7	Right front door speaker group connector sleeve (+ signal)	7G
Z28/8	Right front door speaker group connector sleeve (? signal)	6G
Z28/18	Sound system/antenna control connector sleeve	5D 17E
Cross Section of Wire may differ from Values shown in Wiring Diagram. Changes in Cross Section of Wire will be shown framed.		
Explanations and Notes of Wiring Diagram see Section 00-A Locations/Connections/Overview see Section 00-B/00-C		



